


To Protect Your Warranty, Use Only ENERPAC Hydraulic Oil.

Enerpac recommends that all kit components be installed to insure optimum performance of the repaired product.

Note: The pipe plug, item 37, is used in place of the by-pass valve, item 31, in the P-141.



Repair Parts List

Item	Part Number	Qty.	Description	Item	Part Number	Qty.	Description
2	★ CN767026	2	Enerpac Decal	31	DA5493900SR	1	Bypass Valve (models P142 and 1002)
3	CL341055	1	Acorn Nut	32	DA8802900SR	1	Relief Valve (10,000 - 10,500 PSI)
4	★ CU293167	1	Gasket	33	★ B1036057	1	Spring Pin
5	CN402020SR	1	End Cap (incl. items 3,4,6)	34	★ CU724167	1	Vent Cap Gasket
6	★ B1141517	1	Square Ring	35	DA5483005	1	Pump Base
7	CN766950SR	1	Vent Cap Assembly (incl. items 29,34)	37	A1006245	1	Pipe Plug (P141 only)
8	CL280149	1	Tie Rod				
9	CN782025SR	1	Reservoir (yellow incl. items 2,3,4,6,10,34)				
9	DA3886025	1	Reservoir (red incl. items 2,3,4,6,10,34)				
10	★ B1131517	1	Square Ring Seal				
11	★ CB981018	1	Filter				
12	★ DA3702020	2	Spring Cap				
13	CN815006	2	Pipe Plug (.250 - 18 N.P.T.F.)				
14	★ DA1178349	1	Retaining Ring				
15	★ CR215061SR	1	Beam Pin (incl. item 14)				
16	CL915900SR	1	Beam and Handle Assembly				
17	CL342550	1	Handle Grip				
18	P20857	1	Cross Pin				
19	CN412040SR	1	Plunger (incl. item 20,21,22,30)				
20	★ B1018803	1	O-Ring				
21	★ B1010564	1	Back-Up Washer				
22	★ B1010803	1	O-Ring				
23	★ DA1176210	2	Spring				
24	★ B1009016	2	5/16" Ball				
25	★ B1006016	3	7/32" Ball				
26	CL913900SR	1	Spindle Assembly (inc. item 25,27,28)				
27	★ B1007503	1	O-Ring				
28	★ CU921028	1	Truss Head Machine Screw				
29	★ CN780026	1	Fill Decal				

★ Indicates items included in Repair Kit P141K2. For Viton seals, order Repair Kit P142KV1 in place of standard kit P141K2. (Kit contains 2 sets of seals; be sure to replace with identical seal as the one removed from the pump.)



www.enerpac.com